

Problem	Possible Cause/Question/Action	Corrective Action/Answer/Solution
Scale weighing	Verify the battery voltage.	Power on the scale box and monitor
incorrectly		the display during the boot process. It
		will indicate the battery voltage.
		Battery voltage should be
		approximately 6.4 vdc. Anything less
		than 5.8 vdc is not acceptable and the
		scale will not work correctly. Replace
		the batteries.
	Verify the calibration.	Zero the scale and then place the 25
		lb. weight on the chair. If it reads 25
		lbs., it is calibrated and should weigh
		residents correctly. If it does not
		weigh them correctly the problem is
		something else.
	Parts loose/damaged on the carrier	Verify the rails on the carrier are tight.
	assembly.	They are connected directly to the
		load cell and will affect weighing a
		resident. You can also reset all wiring
		connectors inside the scale box.
Scale Touch pad not	Verify ON/ZERO, first and second O in Apollo	Press the ON/ZERO button. Power
working. Cannot	are working.	should come on. If not, verify
enter Calibration		batteries are at least 5.8 volts. If not
mode. Scale does		replace batteries. Press the ON/ZERO.
not turn on.		Power should come on. If not, replace
		the touch pad.
		Press the ON/ZERO button. Power
		should come on. Press the first O in
		Apollo. Every time you push the first
		O in Apollo, it will recall the last
		weight measured. If it does not,
		replace the touch pad
		Press the ON/ZERO button. Power
		should come on. Press the last O in
		Apollo. Every time you push the last O
		in Apollo, it will toggle between lbs.
		and kg. If it does not, replace the
		touch pad