

Air Spa Blower Troubleshooting

Problem	Possible Cause/Question/Action	Corrective Action/Answer/Solution
Blower not working	Check GFCI/power to the tub	Reset GFCI/supply 13 amps of power
Blower still not working	Unplug blower from the controller and plug it into the power source	If the blower runs, then trouble-shoot the controller and key pad.
Blower still not working	Did the blower get wet?	Let the blower dry and try again. If dry, replace blower
If the blower runs for a few minutes, then stops	The blower may have over heated and shut itself off	Let the blower cool for 30 minutes and clean any clogged jets.
Check the controller	Plug the known good blower back into the controller	Unplug the key pad from the controller
	Jumper the red and green wires on the controller connector.	If the blower runs, replace the keypad. If the blower does not run, replace the controller.